




# HIGH SPEED DIGITAL INDICATOR

MODEL DLS-5037

## OPERATION MANUAL



## TOYO SOKKI CO.,LTD.

964-24 Nippa-cho Kohoku-ku, Yokohama 223-0057 Japan

TEL +81-45-540-8353

FAX +81-45-544-8354

	Page
§ 1. SUMMARY .....	4
§ 2. INSTALLATION AND CONNECTION METHOD OF THE UNIT .....	5
2-1) Installation environment of the unit .....	5
2-2) To obtain stable measurement .....	5
§ 3. APPEARANCE AND EACH PART NAME.....	6
3-1) Appearance of the unit .....	6
3-2) Name of each part.....	6
§ 4. OPERATION.....	10
4-1) Measuring Mode .....	10
4-2) Function Mode .....	14
4-3) Test Mode.....	14
§ 5. PROCEDURE OF OPERATION .....	15
5-1) Procedure of setting a function .....	15
5-2) Procedure of integration .....	15
5-3) Procedure to indicate bar graph .....	16
5-4) Procedure to indicate percentage .....	17
5-5) Procedure to convert unit .....	17
§ 6. CALIBRATION .....	18
6-1) Calibration Lock .....	18
6-2) Actual Load Calibration.....	18
6-3) Equivalent Input Calibration .....	19
§ 7. OPTION (AT THE TIME OF SHIPMENT).....	20
7-1) 4~20mA current output (OP-1) / $\pm 10$ V voltage output (OP-2).....	20
7-2) RS-232C (OP-3) / RS-485 (OP-7) .....	21
7-3) BCD data output (OP-6) .....	24
§ 8. FUNCTION .....	25
8-1) Basic operation .....	25
8-2) Setting function .....	25
8-3) Comparator function .....	26
8-4) External output.....	27
8-5) External input.....	28
8-6) Analog output.....	28
8-7) Serial output .....	29
8-8) BCD data output .....	30
8-9) Weighing condition setting .....	30
8-10) Calibration .....	32
§ 9. TEST MODE.....	33
9-1) Basic operation .....	33
9-2) Test item .....	33
§ 10. TROUBLESHOOTING .....	35
10-1) Basic check point .....	35
10-2) Precautions at the time of calibration .....	35
10-3) Countermeasures for unusual display .....	35
10-4) Judgement whether this unit has malfunction .....	35
10-5) Checking a sensor (Load Cell).....	36
§ 11. SPECIFICATIONS .....	37
11-1) A/D convert part .....	37
11-2) Display part .....	37
11-3) Zero point and Sensitivity correction .....	37
11-4) I/O part.....	38
11-5) Option.....	38

11-6) General .....	39
§ 1 2. LIST OF MODELS AND ACCESSORIES .....	39
12-1) Model.....	39
12-2) Accessories .....	39
§ 1 3. TERMINAL ARRAY .....	40
13-1) Terminal array.....	40
§ 1 4. DIMENSIONAL DRAWING.....	41
§ 1 5. FUNCTIONAL BLOCK DIAGRAM .....	41

※This operation manual conforms to program version 2.00 and later.

This document is translated from MA4-234-R1 (Japanese)

---

## § 1. Summary

---

This unit is a high speed sampling, 2,000 times per second, digital indicator for exclusive use of the strain gauge transducer that is most suitable for a system which needs high-speed control such as filling object, pressure or torque.

Frequency characteristic of analog filter of this unit is selectable by 2 switches on rear panel. Selectable 12 cut-off frequencies help to response various kind of input signal easily.

This unit has a main LED indicator to display the measured value and a sub LED indicator to display Tare Subtraction, Preset Tare, Integrated value, Hold level, it also can display the percentage of the measurement level against output of maximum load as the bar graph or numeric value. Also display a unit or the number which is converted.

This unit has 6 points of external comparator output as upper / lower limit judgement and window comparator judgement as LO/GO/HI. Also has 6 points of external command input which are able to be allocated as various function.

As an option, This unit can be installed as 4~20mA current output,  $\pm 10V$  voltage output, RS-232C/485 and BCD output. (specified at the time of order)

The power supplied voltage is AC100 to 240V or DC24V (specified at the time of order).

---

## § 2. Installation and connection method of the unit


---

### 2-1) Installation environment of the unit

- 1) Operation temperature range of this unit is  $-10^{\circ}\text{C}\sim+40^{\circ}\text{C}$ .  
Please install the unit where the place does not have direct sunlight and condensation.
- 2) The power supplied voltage is AC100~240V(as standard) or DC24V(as option).  
Recommend to use a constant voltage transformer if AC power supply is not stable.
- 3) This unit can be installed to the panel. Please install by using attached metal fittings.
- 4) Terminal array are 7.62mm pitch crimped terminals. Wire to them using Crimp terminal for M3 up to 6mm width. Please confirm the cable specification before wiring.
- 5) The shield of each cable should be grounded to one of this unit or each connected unit.


### 2-2) To obtain stable measurement

When a sensor of strain gauge (i.e., Load Cell, Pressure gauge) is amplified by an amplifier or is connected to an indicator, the value may fluctuate or may not be stable.



( Fig. 1 )

This is because of difference of an electric potential between a sensor part and an amplifier / indicator part. It is induced from electricity rounding of general commercial power supply (AC100V/AC200V).



( Fig. 2 )


The most effective way to improve stability is to use a cable to connect an Earth terminal of an amplifier / indicator to a case or chassis of sensor, like Fig 2.

If it is difficult to find an Earth terminal of sensor side, loose bolt of metal case of sensor and connect the cable. Please make the electric potential be same as possible.

In case that a sensor and amplifier / indicator have installed apart separately, stability improves when an Earth terminal of indicator / amplifier and metal case of sensor connect to the nearest earth of each. But if they are apart far from each other, it may not bring a good result due to different electric potential of the earth. However, in such a case, stability improves if connecting a cable as Fig 2.

### § 3. Appearance and Each part name

#### 3-1) Appearance of the unit



#### 3-2) Name of each part

- ① Main Display  
Indicates the measured value in Measuring Mode.  
Also indicates a guidance to show items in Function Mode.

- ② Sub Display  
Indicates a guidance in order whenever push **DISP SEL** key.  
Also indicates the setting value listed below

No.	Guide display	Operation	
1	None	Guide display OFF	
2	⌊ r.	Tare subtraction	
3	P ⌊.	Preset tare subtraction	
4	Γ.	Integration target gap	
5	⌊.	Integration target value	
6	n.	Integration number of times	
7	S - H.	Sampling Hold value	
8	P - H.	Peak Hold value	
9	b - H.	Bottom Hold value	
10	P - P.	Peak to peak Hold value	
11	⌊ u ⌊.	Bar Graph	Select one of them
	P c ⌊.	Percentage	
	c u.	Unit conversion	

- ③ Status Display  
Showing status of this unit by lighting ON/OFF each LED.
- ST : The measured value is stable
  - CZ : Center zero. The measured value is within 1/4 scale division.
  - GROSS : Displaying Gross value
  - AZ : Tare subtraction is in operation
  - PT : Preset tare subtraction is in operation
  - HOLD : Hold function is in operation
  - \* : User selected function  
The function is selected at [ F u n c / R S t. d S P ] in Function Mode
    - a) Close to zero
    - b) In the range of zero trucking
    - c) Integration is in operation

④ Comparator judgment Display

- SP1 : Upper / Lower limit judgment of set point 1  
SP2 : Upper / Lower limit judgment of set point 2  
SP3 : Upper / Lower limit judgment of set point 3  
SP4 : Upper / Lower limit judgment of set point 4  
LO : Measured value < (Reference value -Lower limit value)  
GO : (Reference value -Lower limit value) ≤ Measured value ≤ (Reference value + Upper limit value)  
HI : (Reference value + Upper limit value) < Measured value

Comparator function is selected at [FUNC/COMP] in Function Mode.

⑤ Key switches

**FUNC** : Function Mode

Enter Function Mode when pushing this key for one second.

This unit is still measuring even in Function Mode.

Return to Measuring Mode when pushing **ESC** key.

During Function Mode, the classification of function is displayed in turn when pushing this key.

Please refer to section §8 Function for the details.

**\*←** : User selected function

Perform an allocated function when pushing this key. The function is selected by [FUNC/RS.E.E.Y] in Function Mode.

- a) **ZER** : Perform zero correction of Gross value (GROSS) when pushing this key for one second. To cancel zero correction, push this key and **ESC** key simultaneously.  
Zero correction is not vanished even if turn power OFF.
- b) **INT** : Integrate the measured value. Reset an integrated value and the number of times of integration to 0 when pushing this key and **ESC** key simultaneously. If the integration condition is not met, and pushing this key for two seconds, can cancel the last integration amount. Integrated value is not vanished even if turn power OFF.
- c) **INT** : Cancel the last integration operation when this key is pushed for one second. Reset an integrated value and the number of times of integration to 0 when pushing this key and **ESC** key simultaneously.
- d) **COMP** : Resume Hold operation of comparator output.
- e) **RS.E.E.Y** : Output data to RS-232C/485 for once.

In Function Mode, select a digit of the setting value toward left or select a classification of function in reverse order.

**DISP SEL** : Selection of Sub Display

Each time this key is pushed, the guidance in Sub Display is displayed in order,

(None) → Tare subtraction → Preset tare subtraction → Integration target gap → Integration target value → Integration number of times → Sampling Hold value → Peak Hold value → Bottom Hold value → Peak to peak Hold value → Conversion.

Conversion has three items and is selected at [FUNC/UNIT] in Function Mode.

LEDs of Sub Display will be lighted OFF when pushing this key for 2 seconds.

Memorize the last item even if turn power OFF.

**HOLD**△ : Start/Stop to Hold

LED [HOLD] at Status Display will be lighted ON when Hold is in operation.  
Clear the Hold value when pushing this key for 2 seconds. This unit can hold the 4 type of Hold value simultaneously and choose one of them at Sub Display by **DISP SEL** key, as sampling Hold / peak Hold / bottom Hold / peak to peak Hold.  
In Function Mode, increase the selected value or select the item of function in order.

**MEMO** : Memorize

When a Sub Display indicates 'Preset tare subtraction', 'Integration target gap' or 'Conversion' and pushing this key for 1 second, appear the numerical setting value even in Measuring Mode.  
In Function Mode, memorize the setting value, candidate or item.

**▽N/G** : Alternate Net / Gross value

Press this key to alternate to display the Net / Gross value.  
LED [GROSS] at Status Display will be lighted ON when the Gross value is indicated.  
In Function Mode, decrease the selected value or select the item of function in reverse order.

**AZ** : Auto Zero

Perform Tare subtraction and LED [AZ] at Status Display will be lighted ON when pushing for 1 second.

**▷AZR** : Auto Zero Reset

Cancel Tare subtraction when pushing for 1 second.  
In Function Mode, select a digit of the setting value toward right or select a classification of function in order.

**ESC** : Escape

Keys except **ESC** key are locked when pushing this key for 2 seconds in Measuring Mode. And keys are unlocked pushing it again for 2 seconds.  
In Function Mode, cancel the setting value, candidate or item. And return to Measuring Mode pushing **ESC** key again.

⑥ Load Cell input terminal

⑦ Analog filter switches

Cut off frequency : fc					
		SW2			
SW1		L	ML	MH	H
	X 1	2Hz	20Hz	200Hz	1.8kHz
	X 2	4Hz	40Hz	400Hz	2.9kHz
	X 5	10Hz	100Hz	980Hz	4kHz

⑧ EXC switch: Excitation voltage to Load Cell or a sensor

Select EXC=5V or EXC=2.5V

※ Please do not switch while this unit is in use because it will cause a measurement error after calibration has been done.

⑨ Option mounting port

Either one of RS-232C(OP-3), BCD output(OP-6) or RS-485(OP-7) can be installed into this port.



⑩ I / O connector: Connector for external I/O

Connector for comparator output and external command input.  
They should be wired to an external equipment using attached FCN connector by user.

⑪ A-OUT terminal: Analog output terminal

This is a terminal for 4~20mA current output (OP-1) or  $\pm 10V$  voltage output (OP-2).  
Either one of analog option can be installed.

Please do not connect anything if OP-1 or OP-2 is not installed.

⑫ S-OUT terminal: Current Loop serial output

Terminal for exclusive use of TOYO external peripheral equipment.

⑬ E : Earth terminal

Connect earth-line of ground resistance  $100\Omega$  or less to this terminal.

⑭ Power Terminal

Please do not connect other than specified power supplied voltage.  
Please be careful of the polarity when connecting to DC24V.

⑮ Metal fittings for panel

Put metal panel between front of this unit and this fittings and tighten with screw.

---

## § 4. Operation

---

### 4-1) Measuring Mode

#### 1) Over load

This is a function to inform over load of Load Cell. Set a rated capacity of Load Cell at [C R L / C R P] in Function Mode. If the measured value exceeds a setting value of [C R L / C R P], blink the measured value to warn of over load but keep measuring. Tare subtraction and Integration operation cannot be done during over load.

#### 2) Tare subtraction

Press [AZ] key for 1 second to memorize the measured value as Tare value. LED [AZ] at Status Display is lighted ON during Tare subtraction. Press [AZR] key for 1 second to cancel Tare subtraction.

Tare value is memorized in a non-volatile memory and cannot be vanished even after powered OFF

#### 3) Zero correction

Select [Z E r o] at [F u n c / R 5 t. P E Y] in Function Mode to allocate [\*<] key to perform zero correction. Pressing [\*<] key for 1 second, correct zero and memorize as Gross zero value. Pressing [\*<] key and [ESC] key simultaneously, cancel zero correction.

Range of zero correction is determined at [F. C R L / Z r. L n i t] in Function Mode, which enables what percentage of the rated capacity is effective to perform zero correction.

Zero correction value is memorized in a non-volatile memory and cannot be vanished even after powered OFF.

#### 4) Net value / Gross value

Every time pressing [N/G] key, alternates to display Net value and Gross value. LED [GROSS] at Status Display is lighted ON during Gross value is displayed.

#### 5) Preset Tare subtraction

This is a function for an object that has a known container weight (Tare value) beforehand.

Select [P - t A r e] at [F u n c / n E t] in Function Mode and set container weight at [F u n c / P - t A r e] in Function Mode.

Range of setting value is -99999 to +99999.

Tare subtracted value appears on Main Display and keep it subtracted afterward. LED [PT] at Status Display is lighted ON.

When a preset Tare value is displayed on Sub Display as [P t. xxxxx], pressing [E] key for 1 second enables to set Tare value on Sub Display.

Choose one either Preset Tare subtraction or Net operation.

#### 6) Net operation

This is a function for an object that has a known content amount (Net value) beforehand.

Select [P - n E t] at [F u n c / n E t] in Function Mode and set a content amount at [F u n c / P - t A r e] in Function Mode.

Range of setting value is -99999 to +99999.

LED [PT] at Status Display is lighted ON.

Content amount appears on Main Display when [AZ] key is pressed at Measuring Mode and increase / decrease amount is displayed from that moment. Memorize the value of subtracting content amount from the measured value.

Choose one either Preset Tare subtraction or Net operation.

## 7) Hold

- a) Sampling Hold :Fix a display value to the number when start Hold operation
- b) Peak Hold :Indicate maximum value during Hold operation
- c) Bottom Hold :Indicate minimum value during Hold operation
- d) Peak to peak Hold :Indicate maximum-minimum value during Hold operation

Every time pressing **HOLD** key, it alternates to start and stop Hold operation. LED [HOLD] at Status Display is lighted ON during Hold operation.

Select each Hold value to display on Sub Display pressing **DISP SEL** key. Each Hold operation is working during Hold operation. Each Hold value is cleared when pressing **HOLD** key for 2 seconds. Each Hold value is vanished after powered OFF.

## 8) Sub Display

Each time **DISP SEL** key is pushed, guidance is displayed in order,

(None) → Tare subtraction → Preset tare subtraction → Integration target gap → Integration target value → Integration number of times → Sampling Hold value → Peak Hold value → Bottom Hold value → Peak to peak Hold value → Conversion

Conversion has three items and is selected at [F u n c / U n i t] in Function Mode. LEDs of Sub Display is lighted OFF when pushing this key for 2 seconds.

## 9) Conversion

Bar graph, percentage or unit conversion of the measured value is displayed on Sub Display. Select one of three items as follows at [F u n c / U n i t] in Function Mode.

- a) **L E U E L** :Bar graph indication  
Indicate the percentage of the preset value in bar graph.  
Level 10% 50% 60% 100%

Preset value is set at [P c t. xxxxx] in Sub Display, which appears when key is pressed for 1 second.

After the preset value is input and press key, [S E t] appears for one second and display a bar graph.

Preset value is common to b) Percentage indication.

- b) **P E r c E n t** :Percentage indication  
Indicate the percentage of the preset value with one decimal place.

Preset value is set at [P c t. xxxxx] in Sub Display, which appears when key is pressed for 1 second.

After the preset value is input and press key, [S E t] appears for one second and display percentage of the preset value with one decimal place.

Preset value is common to a) Bar graph indication.

- c) **C o n u E r t** :Convert to the value divided with the preset value.

Preset value is set at [C u. xxxxxx.] in Sub Display, which appears when key is pressed for 1 second.

After the preset value with decimal point is input and press key, [S E t] appears for one second and proceeds to [d P. xxxxxx] where decimal point of converted value is set.

After decimal point is input and press key, [S E t] appears for one second and display the value divided with the preset value with preset decimal point.

## 10) Integration

### a) Integration by key operation

Select [  $\int$  ] at [ F u n c / R S E T ] in Function Mode where allocate a function to [ \* ] key. Each time to press [ \* ] key, [  $\int$  ] is displayed in Sub Display for 1 second and add Net value to the integrated value.

When condition of integration has already been set at [ F u n c / E L C n d ] in Function Mode, If it is not fulfilled the condition, cancel the last addition operation by pressing [ \* ] key for 1 second.

When [ \* ] and [ ESC ] key is pressed simultaneously, [  $\int$  ] is displayed in Sub Display for 1 second and clear the integrated value.

### b) Automatic integration

The sixth digit of setting value at [ F u n c / E L C n d ] in Function Mode is set '1'.

When the measured value is stable but not close to zero, add Net value to the integrated value automatically. After an addition operation is completed, next addition is not done until the measured value is back to close to zero.

### c) Clear integrated value.

Clear integration when automatic integration or external integration command is selected.

Select [  $\int$  ] at [ F u n c / R S E T ] in Function Mode where allocate a function to [ \* ] key.

When pressing [ \* ] key for 1 second, [  $\int$  ] is displayed in Sub Display for 1 second and cancel the last addition operation.

When [ \* ] and [ ESC ] key is pressed simultaneously, [  $\int$  ] is displayed in Sub Display for 1 second and clear the integrated value.

### d) Integration by external command.

At [ I n ] in Function Mode, allocate external command as follows to operate integration.

R d d : Addition operation  
c R n c E L : Cancel addition operation  
E E L - c L E R r : Clear the integrated value

## 11) Target value of integration

Select [ T ] in Sub Display during pressing [ DISP SEL ] key and the value of [ T ] is called as 'target gap'.

$$\text{Target gap} = (\text{integrated value} + \text{measured Net value}) - \text{Target value}$$

Target value is set at [ xxxxxxxx ] in Sub Display, which appears when [ T ] key is pressed for 1 second.

If a target value is set to '0', target gap equals the sum of integrated value and measured Net value, which easily anticipate the value before addition operation.

Remind that after addition operation has done, target gap is not updated until the measured value is back to close to zero.

## 12) Close to zero

This function determines the range of close to zero when an object or load is put down from a scale and let it know the measuring has done.

Set numerical value of range from zero at [ F u n c / n E R r - 0 ] in Function Mode.

This function is utilized as judgement condition of automatic integration, judgement range of comparator, reset of comparator output and automatic serial data output.

## 13) Comparator


This unit has four comparators with upper / lower limit judgement and window a comparator with HI/GO/LO. It can output 6 comparator judgements in total. Output of judgement of SP4 / LO is selectable from one of them.

Numerical value and condition of comparator is set at [  $\square \square \bar{n} P$  ] in Function Mode.

a) Upper limit judgement

Output ON : Measured value  $\geq$  Quantitative value - Fall value


Output OFF : Measured value  $<$  Quantitative value - Fall value - Hysteresis value



b) Lower limit judgement

Output ON : Measured value  $\leq$  Quantitative value + Fall value

Output OFF : Measured value  $>$  Quantitative value + Fall value + Hysteresis value



c) Delay time


External output can be delayed after comparator perform upper / lower limit judgement.

Set numerical value at [  $\square \square \bar{n} P / d L Y$  ] in Function Mode.

Delay time = set value x 0.5ms. i.e.) 2000(set value) x 0.5ms = 1 second

d) HI/GO/LO Window Comparator


$LO < (Reference - Lower\ limit\ value) \leq GO \leq (Reference + Upper\ limit\ value) < HI$



When hold of judgement (Fourth, third digit = 1) is set at [  $\square \square \bar{n} P / \square \square \bar{n} d \square$  ] in Function Mode, use together with stable (First digit = 1).


14) External output

This unit has 6 Open Collector output as external output. Each output content is selected from comparator judgement or operation status at [  $\square \square \bar{n} E$  ] in Function Mode.



### 15) External command input

This unit has 6 Open Collector input as external input. Each command is selected at [ i n ] in Function Mode.



### 16) Current Loop serial output

Interface for exclusive use of TOYO peripheral equipment such as ED-3020/3021(external large LED display), EP-3030(external printer).

It is isolated from internal circuit and connected to peripheral equipment using current loop signal 0~20mA.

Output data is selected at [ 5 E r , R L / C L . 5 E L ] in Function Mode.

Data output period is synchronized with renew period of displaying LED set at [ F . c R L / d 5 P . c Y c ] in Function Mode. However maximum of data output period is 16 times/second (about 60ms)

### 17) Key lock

Key lock function can prevent wrong key operation.

Pressing any key other than **ESC** key in key lock status, [ L o c k ] is displayed in Sub Display and doesn't accept key operation. But external command input is acceptable.

Pressing **ESC** key in Measuring Mode for 2 seconds can alternate Lock and Unlock key operation.

### 4-2) Function Mode

This is a mode for setting various function.

Pressing **FUNC** key for 1 second in Measuring Mode can enter Function Mode.

Refer to function table at section §8 Function for details.

### 4-3) Test Mode

This is a mode for checking operations of this unit.

The response of external I/O signal and indication of display is different during Test Mode. Please take measures to connected external equipment to keep it from abnormality.

To enter Test Mode, keep pushing **ESC** key while powering ON, or pressing **ESC** key 3 times immediately after powered ON. Or setting [ o n ] at [ F u n c / E E 5 E ] of Function Mode using **←** or **→** key and pressing **ESC** key 3 times can enter Test Mode.

## § 5. Procedure of operation

### 5-1) Procedure of setting a function

Refer to function table at section §8 Function for details.

	Guide display	Operation	Detail
1	(Measuring Mode)	–	Press <b>FUNC</b> key for 1 second.
2	<b>F u n c</b>	Function Mode	
3	(Classification of Function Mode)	Select classification	Pressing <b>FUNC</b> key, display classification. Pressing <b>◀ ▶</b> key, display classification.
4	(Item of classification)	Select item	Pressing <b>▲ ▼</b> key, display item. Setting value or candidate is displayed in Sub Display.
5		Setting candidate	Pressing <b>◀ ▶</b> key, display candidate. Candidate is blinking while setting.
6		Setting numerical value	Pressing <b>◀ ▶</b> key, select the digit to change. The digit to change is blinking. Pressing <b>▲ ▼</b> key, change the numerical value.
7		Setting polarity	Highest digit may set polarity '-' pressing <b>▲ ▼</b> key in case of the setting range from minus.
8		Memorize setting	After setting value or candidate has been done, press <b>↵</b> key to memorize. [5 E E] is displayed in Sub Display and proceed to the next item.
9		Leave without setting	Pressing <b>ESC</b> key while setting, return to the former value or candidate.
10	(Classification of Function Mode)	Leave item	Pressing <b>ESC</b> key again, return to display classification.
11	(Measuring Mode)	Leave Function Mode	Pressing <b>ESC</b> key again return to Measuring Mode.

### 5-2) Procedure of integration

Target gap = ( integrated value + measured Net value ) - Target value

	Guide display	Operation	Detail
1	<b>A 5 E . E E Y</b>	Setting addition function beforehand (Either of <b>A 5 E . E E Y</b> or <b>I n</b> )	Select [ <b>E o E A L</b> ] at [ <b>F u n c / A 5 E . E E Y</b> ] in Function Mode
	<b>I n</b>		Set [ <b>A d d</b> ] and [ <b>E E L - c L E A r</b> ] against two external input at [ <b>I n</b> ] in Function Mode. (Set In5,6 at the time of shipment)
2	<b>E E L . c n d</b>	Setting condition of addition operation	Set condition at [ <b>F u n c / E E L . c n d</b> ] in Function Mode and return to Measuring Mode.
3	<b>Γ.</b>	Select target gap	Select target gap in Sub Display pressing <b>DISP SEL</b> key.
4	(setting value)	Setting target value	[xxxxxxx] is appeared in Sub Display after pressing <b>↵</b> key for 1 second.
			Using <b>◀ ▶ ▲ ▼</b> key to set target value.
			Pressing <b>↵</b> key to memorize.
5	<b>Γ.</b>	No load on a scale	Measured value is zero in Main Display.
Display target gap		Minus of target value is in Sub Display.	
6		Put a load on a scale (Start to measure)	Measured value of a load in Main Display. 'measured NET value - target value' is in Sub Display.
7		Addition operation	Pressing <b>* ◀</b> key or external command

			input [ R d d ] operates addition function. Measured Net value is added to integrated value. 'integrated value - target value' in Sub Display.
8		Unload from a scale	Measured value is zero in Main Display. Still 'integrated value - target value' is in Sub Display.
9		Put a load on a scale (Next measurement)	Measured value of a load in Main Display. 'integrated value + measured NET value - target value' is in Sub Display.
10		Repeat until reach target	Repeat same procedure from 7 to 9 until target gap in Sub Display reach to zero.
11		Finish to measure	Pressing [*<] and [ESC] key simultaneously or external command input [ t t L - c L E R r ] let integrated value to clear.
12		Restart to measure	Repeat same procedure from 4 in case of changing target value. Repeat same procedure from 5 in case of same target value.

Example) Measure load amount on cargo bed of truck while loading with a crane

- |  |                        |
|--|------------------------|
| ① Set maximum load of 10ton (10,000kg) as target value                               | target gap = -10,000kg |
| ② 1st load = 2,000kg   | target gap = -8,000kg  |
| ③ Press [*<] key or external command to add  |                        |
| ④ 2nd load = 3,000kg   | target gap = -5,000kg  |
| ⑤ Press [*<] key or external command to add  |                        |
| ⑥ 3rd load = 4,000kg   | target gap = -1,000kg  |
| ⑦ Press [*<] key or external command to add  |                        |
| ⑧ 4th load = 1,200kg   | target gap = +200kg    |
| Target gap exceeds +200kg. Change to more lightweight load.                          |                        |
| Before addition operation, integrated value is not settled thus can be recalculated. |                        |
| Change 4th load = 900kg  | target gap = -100kg    |
| ⑨ Press [*<] key or external command to add  |                        |
| ⑩ Finish measuring with margin 100kg remained  |                        |

If target value is set to '0', target gap equals the sum of integrated value and measured Net value, which easily anticipate the value before addition operation.

### 5-3) Procedure to indicate bar graph

Indicate 10 step of bar graph against preset value.

Bar graph = measured value / preset value X 10

	Guide display	Operation	Detail
1	U n i t	Select unit	Select [ L E u E L ] at [ F u n c / U n i t ] in Function Mode and return to Measuring Mode.
2	L u L.	Select Sub Display	Press [ DISP SEL ] key and select [ L u L. ]
3	P c t. xxxxx	Set preset value (Common to 5-4))	Press [ ] key for 1 second
4			Set preset value using [ < ] [ > ] [ Δ ] [ ▽ ] key
5			Press [ ] key to memorize
6	(Measuring Mode)		Return to Measuring Mode



5-4) Procedure to indicate percentage

Indicate percentage of preset value with one decimal place.

Percentage = measured value / preset value X 100.0

	Guide display	Operation	Detail
1	U n i t	Select unit	Select [P E R C E N T] at [F u n c / U n i t] in Function Mode and return to Measuring Mode.
2	P c t.	Select Sub Display	Press [DISP SEL] key and select [P c t.]
3	P c t. xxxxx	Set preset value (Common to 5-3))	Press [ENT] key for 1 second Set preset value using [←] [→] [▲] [▼] key Press [ENT] key to memorize
4	(Measuring Mode)		Return to Measuring Mode

5-5) Procedure to convert unit

Converted value = measured value / preset value

	Guide display	Operation	Detail
1	U n i t	Select unit	Select [C o n v E r t] at [F u n c / U n i t] in Function Mode and return to Measuring Mode.
2	C u.	Select Sub Display	Press [DISP SEL] key and select [C u.]
3	C u. xxxxxx.	Set preset value with decimal point	Press [ENT] key for 1 second Set preset value using [←] [→] [▲] [▼] key. Using [←] [→] key, select highest digit + one [←] key or lowest digit + one [→] key to start to blink decimal point. Using [▲] [▼] key, select decimal point Press [ENT] key to memorize
4	d P. xxxxxx	Set decimal point of converted value	Set decimal point using [←] [→] key Press [ENT] key to memorize
5	(Measuring Mode)		Return to Measuring Mode

Example 1) In case of converting to N (newton)

When converting weight to force,

① 1N = 0.10197kgf

② Unit in Main Display is kilogram and if it is 123.4kg,

③ Preset value should be 0.10197

④ Decimal point of converted value should be 0.0 (one digit after decimal point)

Converted value (newton) = 123.4kg ÷ 0.10197(preset value) = 1210.2 N

Example 2) In case of converting to L (litre)

When monitoring the remains of liquid nitrogen in a tank

① Density of liquid nitrogen is about 0.809g/cm<sup>3</sup> = 809g/L

② Unit in Main Display is kilogram and if it is 12.34kg,

③ Preset value should be 000.809 (suit to kg)

④ Decimal point of converted value should be 0.00 (two digit after decimal point)

Converted value (litre) = 12.34kg ÷ 0.809(preset value) = 15.25 L

Example 3) In case of converting to the number of articles

When counting the number of articles in a container

① Weight of one article is = 567.89g, assumingly

② Unit in Main Display is kilogram and if it is 123.4kg,

③ Preset value should be 0.56789 (suit to kg)

④ Decimal point of converted value should be 0 (no decimal point)

Converted value ( the number of articles ) = 123.4kg ÷ 0.56789(preset value) = 217

## § 6. Calibration

As for calibration method, there are two kinds of calibration as [Equivalent Input Calibration] which input the equivalent output voltage of the Load Cell by key operation (available only EXC=5V), and as [Actual Load Calibration] which use a weight as an actual load. Calibration can be done by either method but it will be operated by the last performed calibration value. It is recommended to calibrate by actual load as much as possible.

To correct non-linearity of a sensor or Load Cell, This unit is able to calibrate five span points. If it is not necessary, Set 0 in [CAL / CAL 2~5] of Function Mode. After non-linearity correction is done, span correction value is re-sorted ascending order.

### 6-1) Calibration Lock

There is a function of calibration lock for not to break a calibrated value by wrong operation. If span calibration is going to be performed, it is displayed with [LOCK] and does not accept a change during CAL LOCK. But zero point calibration can be performed.

Calibration lock procedure as follows.

	Guide display	Operation	Detail
1	(Measuring Mode)		Push <b>ESC</b> key while turning power ON, or press <b>ESC</b> key 3times immediately after powered ON.
2	CAL UNLOCK	Select candidate	Use <b>←</b> <b>→</b> key to select [UNLOCK] : Calibration permitted [LOCK] : Calibration prohibited Press <b>↵</b> key to memorize
3	8.8.8.8.8.8. 8.8.8.8.8.8.8.8.	Reset	Reset automatically
4	(Measuring Mode)		Return to Measuring Mode

### 6-2) Actual Load Calibration

	Guide display	Item	Operation
1	CAL UNLOCK	Cancel Cal. lock	Cancel calibration lock if locked
2	CAL	Start Calibration	Enter [CAL] in Function Mode Press <b>△</b> key to the next item
3	d.P o i n t 0	Decimal point position	Use <b>←</b> <b>→</b> key to select decimal point Press <b>↵</b> key to memorize
4	S c L d i u 1	Minimum scale	Use <b>←</b> <b>→</b> key to select minimum scale Press <b>↵</b> key to memorize
5	CAP 99999	Rated capacity of Load Cell	Use <b>←</b> <b>→</b> <b>△</b> <b>▽</b> key to set numeric value. Set '99999' if not needed. Press <b>↵</b> key to memorize
6	CAL 0 0	Zero Calibration	Put no load on Load Cell
7	CAL 0 00000		Press <b>←</b> or <b>→</b> key to start to blink one of the digit of '0' in Sub Display. Don't change '00000'. Press <b>↵</b> key to memorize
8	CAL 1 10000	Span Calibration	Put a reference weight on Load Cell. Prepare a weight as heavy as possible within the feasible range of Load Cell. Use <b>←</b> <b>→</b> <b>△</b> <b>▽</b> key to set numeric value of a reference weight. Press <b>↵</b> key to memorize
9	CAL ~ 2 5 0		Non-linearity correction

			'CAL 1' until necessary span number ※Calibration value of span is sorted ascending order after calibration is completed
10	(Measuring Mode)		Press <b>ESC</b> key several times until return to Measuring Mode

### 6-3) Equivalent Input Calibration

Only effective when EXC=5V. When EXC=2.5V, please perform actual load calibration.

	Guide display	Item	Operation
1	CAL UNLOCK	Cancel Cal. lock	Cancel calibration lock if locked
2	CAL	Start Calibration	Enter [CAL] in Function Mode Press <b>▲</b> key to the next item
3	d.P o i n t 0	Decimal point position	Use <b>◀ ▶</b> key to select decimal point Press <b>↵</b> key to memorize
4	S c L d i u 1	Minimum scale	Use <b>◀ ▶</b> key to select minimum scale Press <b>↵</b> key to memorize
5	CAP 99999	Rated capacity of Load Cell	Use <b>◀ ▶ ▲ ▼</b> key to set numeric value. Set '99999' if not needed Press <b>↵</b> key to memorize
6	CAL 0 0	Zero Calibration	Press <b>▲</b> key 6 times to proceed to equivalent zero calibration.
7	E.0.A d J 0.00000	Equivalent zero input of Load Cell	Use <b>◀ ▶ ▲ ▼</b> key to set a zero voltage (mV/V) of Load Cell Press <b>↵</b> key to memorize
8	E.S.P A n 1 10000	Display value of equivalent span of Load Cell	Use <b>◀ ▶ ▲ ▼</b> key to set display value of span amount Press <b>↵</b> key to memorize
9	E.S.A d J 1 1.00000	Equivalent span input of Load Cell	Use <b>◀ ▶ ▲ ▼</b> key to set span voltage (mV/V) of Load Cell Press <b>↵</b> key to memorize
10	E.S.P A n 2 ~ E.S.P A n 5 0	Non-linearity correction	Set '0' and memorize when non-linearity correction is not necessary When non-linearity correction is going to be made, operate same procedure as 'E.S.P A n 1' and 'E.S.A d J 1' until necessary span number ※Calibration value of span is sorted ascending order after calibration is completed
11	(Measuring Mode)		Press <b>ESC</b> key several times until return to Measuring Mode



7-2) RS-232C (OP-3) / RS-485 (OP-7)

In serial data interface of RS-232C or RS-485 conformity, it corresponds with two-way communication by the Half Duplex system.


It is isolated from internal circuit.

RS-485 can allocate identification number of connected unit from L01 to L99. (Maximum number of connectable unit is ten).

Writing 'non' as identification number doesn't identify the unit, which result in one to one communication. Interface of RS-485(OP-7) has internal termination resistance. If this unit is connected at the terminal end, it should make short between ⑤ and ⑥ of RS-485 terminal.

1) Specifications

Interface standard	EIA RS-232C conformity or RS-485 conformity(4 lines) RS-485 Maximum connected unit is ten units
Communication Protocol	Start-Stop Synchronous type / Half Duplex bi-directional
Command speed	2400, 4800, 9600, 19200, 38400bps
Communication Format	ASCII code, alphabet should be a capital letter



CR=0DH, LF=0AH



	1	2	3	4	5	6	7	8	9	10	11	12
Non decimal point	W	T	,	±	0	1	2	3	4	5	CR	LF
With decimal point	W	T	,	±	1	2	3	4	.	5	CR	LF
Over Load	O	L	,	±	9	9	9	9	.	9	CR	LF

Example 1) ID='non' when RS-232C or RS-485

Transmit from host:PTR,+012345<CR><LF> → Response :PTR,1234.5<CR><LF>

Example 2) ID=01 (other than 'non') when RS-485

Transmit from host:L01,PTR,+012345<CR><LF> → Response :L01,PTR,1234.5<CR><LF>



2) Communication Command

Command (Description)	Response ('←' : same as command)	The number of digit	Function	Remarks
REQ (Request)	WT, +#####	6	Down-link demand	
ZRO (Zero)	←	-	Zero correction	
ZRC (Zero Clear)	←	-	Clear zero correction	
TRE (Tare)	←	-	Tare subtraction	
DAZ (Digital Auto Zero)				
TRC (Tare Clear)				
AZR (Auto Zero Reset)	←	-	Clear tare subtraction	
NET (Net)	←	-	Display Net value	
GRS (Gross)	←	-	Display Gross value	
NTQ (Net Data Request)	NET, +#####	6	Down-link demand of Net value	
GSR (Gross Data Request)	GRS, +#####	6	Down-link demand of Gross value	
PTR (Preset Tare)	PTR, +#####	6	Down-link demand of preset tare value	
PTR, +##### (Preset Tare)	←	6	Set preset tare value	Forbid decimal point
RLY (Relay)	RLY, +#####	6	Down-link demand of comparator output #----- :OUT1 -#----- :OUT2 --#---- :OUT3 ---#--- :OUT4 ----#- :OUT5 -----# :OUT6	Correspond 0 = OFF 1 = ON
STA (Status)	STA, +00####	6	Down-link demand of status #--- = Stable -#-- = Zero point --#- = Near zero ---# = Zero tracking	Correspond 0 = OFF 1 = ON
SPn (Set point)	SPn, +#####	9	Down-link demand of Quantitative value of comparator n	n=1~4
SPn, +##### or SPn, +##### (Set point)	←	9 / 6	Set Quantitative value of comparator n	n=1~4 Forbid decimal point
HYS (hysteresis)	HYS, +#####	6	Down-link demand of Hysteresis value	
HYS, +##### (Hysteresis)	←	6	Set Hysteresis value	Forbid decimal point
GOQ (Go data Request)	SGO, +#####	9	Down-link demand of reference value of window comparator	

SGO,+##### or SGO,+##### (Set GO data)	←	9 / 6	Set reference value of window comparator	Forbid decimal point
HIQ (HI data Request)	SHI,+#####	6	Down-link demand of upper limit of window comparator	
SHI,+##### (Set HI data)	←	6	Set upper limit of window comparator	Forbid decimal point
LOQ (LO data request)	SLO,+#####	6	Down-link demand of lower limit of window comparator	
SLO,+##### (Set LO data)	←	6	Set lower limit of window comparator	Forbid decimal point
ADD (Add)	←	-	Addition operation	
TTL (Total)	TTL,+#####	9	Down-link demand of integrated value	
TTN (Total Number)	TTL,+#####	6	Down-link demand of the number of times of integration	
TTC (Total Clear)	←	-	Clear integrated value	
<p>Attach terminator &lt;CR&gt;&lt;LF&gt; at the last of each command.  ##### : number of figures is including decimal point.  (with decimal point '1234.5', without decimal point '012345')</p> <p>Forbid decimal point when setting value.  Attach decimal point as a response of down-link demand.  Attach 'Lmn'(mn: identification number) at the start of each command when identifying connected unit using RS-485. Attaching 'non' makes no use of identification.</p>				

### 3) Error response


Response	Content	Remarks
ERR-01	Memory error, writing error	Writing failure to nonvolatile memory, etc.
ERR-02	Non implementation	Tare subtraction during over load, etc.
ERR-05	Format abnormality	Undefined command, number of the digit of numerical value incorrect, etc.
There is terminator <CR><LF>		

### 7-3) BCD data output (OP-6)

Output data Select at [ b c d / b c d 5 E L ] in Function Mode  
 Interface Open Collector output (photo coupler isolation)  
 Rated output DC30V 30mA (resistance load), saturation voltage 0.6V or less  
 Renew period of data Synchronized with that of displaying. Maximum 20 times/sec. (50ms)  
 Output logic Select positive / negative at [ b c d / b c d L C c ] in Function Mode

Output format 28bit, No decimal point


1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28
STABLE	STROBE	POLARITY	OVERFLOW	Digit 10 <sup>5</sup>				Digit 10 <sup>4</sup>				Digit 10 <sup>3</sup>				Digit 10 <sup>2</sup>				Digit 10 <sup>1</sup>				Digit 10 <sup>0</sup>			
				8	4	2	1	8	4	2	1	8	4	2	1	8	4	2	1	8	4	2	1	8	4	2	1



#### Output pin array

Pin No.	CN1		Signal	
	A side	B side		
Data	1	1×10 <sup>0</sup>	2×10 <sup>0</sup>	Select logic positive / negative
	2	4×10 <sup>0</sup>	8×10 <sup>0</sup>	
	3	1×10 <sup>1</sup>	2×10 <sup>1</sup>	
	4	4×10 <sup>1</sup>	8×10 <sup>1</sup>	
	5	1×10 <sup>2</sup>	2×10 <sup>2</sup>	
	6	4×10 <sup>2</sup>	8×10 <sup>2</sup>	
	7	1×10 <sup>3</sup>	2×10 <sup>3</sup>	
	8	4×10 <sup>3</sup>	8×10 <sup>3</sup>	
	9	1×10 <sup>4</sup>	2×10 <sup>4</sup>	
	10	4×10 <sup>4</sup>	8×10 <sup>4</sup>	
	11	1×10 <sup>5</sup>	2×10 <sup>5</sup>	
	12	4×10 <sup>5</sup>	8×10 <sup>5</sup>	
Status	13	OVER FLOW		Over Flow
			POL ( - )	Polarity (minus)
	14	STROBE		Timing of update data being done
			STABLE	Measured value is stable
	15	E-COM		Common emitter to BCD output
	16	SHL		Shield line of cable

Conformed connector : FUJITSU COMPONET LIMITED FCN-361J032 (32pin female)



( Pin array of BCD output on rear side )



## § 8. Function

### 8-1) Basic operation

- ① Press **FUNC** key for 1 second to enter Function Mode.
- ② Press **FUNC** key to display a classification in order.
- ③ Press **◀ ▶** key to display a classification.
- ④ Press **▲ ▼** key to display an item.
- ⑤ Press **◀ ▶** key to select a candidate or a digit.
- ⑥ Press **▲ ▼** key to change the numeric value of the selected digit.
- ⑦ Press **↵** key to memorize the setting.
- ⑧ Press **ESC** key to cancel the setting or leave Function Mode.

In regard to basic operation, refer to section §5 5-1)

### 8-2) Setting function

F u n c				
No.	Content	Guide display	Setting value or candidate	Operation
1	Preset Tare value	P - t A r E 0	-99999 to +99999	Set numerical value (0 at the time of shipment)
2	Net Calculation	n E t P - t A r E	P - t A r E P - n E t	Preset Tare subtraction (at the time of shipment) Net Calculation
3	Condition of adding operation	t E L. c n d 0 0 0 0 0 0	xxxxx1	Add only when stable
			xxxx1x	Prohibit to add when close to zero
			xxx1xx	Prohibit to add again (unless back to close to zero)
			xx1xxx	Prohibit to add minus data
			x1xxxx	Prohibit to add plus data
			1xxxxx	Add automatically (Add only when stable and back to close to zero once) (000000 at the time of shipment)
4	Close to zero	n E A r - 0 9	0 to 99999	Set numerical value (9 at the time of shipment)
5	Operation of <b>*</b> key	A S t. t E Y Z E r o	Z E r o	Zero correction (at the time of shipment)
			t o t A L	Addition / Integration
			t E L. c L E A r	Clear addition / Clear integration
			c n P. c L E A r	Clear hold of comparator output
			P r i n t	Output data to RS-232C / RS-485 for once
6	Operation of LED '*'	A S t. d S P n E A r - 0	n E A r - 0	Turn ON when measured value is within the range of close to zero (at the time of shipment)
			0 - t r A c t	Turn ON when measured value is within the range of zero tracking
			t o t A L	Turn ON during integration
7	Conversion at Sub Display	U n i t L E u E L	L E u E L	Bar graph indication (at the time of shipment)
			P E r c E n t	Percentage indication
			c o n u E r t	Unit conversion
8	Test Mode	t E S t o F F	o F F	Press <b>◀ ▶</b> key to let 'o n' blink and Press <b>↵</b> key to enter Test Mode.
			o n	

8-3) Comparator function

C O n P				
No.	Content	Guide display	Setting value or candidate	Operation
1	Quantitative value of comparator 1	S P. 1 9 9 9 9 9	-99999 to +99999	Set numerical value  (99999 at the time of shipment)
2	Quantitative value of comparator 2	S P. 2 9 9 9 9 9		
3	Quantitative value of comparator 3	S P. 3 9 9 9 9 9		
4	Quantitative value of comparator 4	S P. 4 9 9 9 9 9		
5	Fall value of comparator 1	S P 1.c 0	0 to 99999	Set numerical value  (0 at the time of shipment)
6	Fall value of comparator 2	S P 2.c 0		
7	Fall value of comparator 3	S P 3.c 0		
8	Fall value of comparator 4	S P 4.c 0		
9	Hysteresis (common to comparator 1-4)	H Y S 0	0 to 99999	Set numerical value  (0 at the time of shipment)
10	Delay time (common to comparator 1-4)	d L Y 0	0 to 9999	Set numerical value Delay time = setting value x0.5ms (0 at the time of shipment)
11	Judgement of comparator 1	S E L. 1 U P - n E t	0 F F	No judgement. No output.
12	Judgement of comparator 2	S E L. 2 U P - n E t	U P - n E t	Upper limit of Net value (at the time of shipment)
13	Judgement of comparator 3	S E L. 3 U P - n E t	d n - n E t	Lower limit of Net value
14	Judgement of comparator 4	S E L. 4 U P - n E t	U P - G r o S S	Upper limit of Gross value
			d n - G r o S S	Lower limit of Gross value
			U P - P E A K	Upper limit of peak value while Hold operation
			d n - P E A K	Lower limit of peak value while Hold operation
			U P - b o t t o m	Upper limit of bottom value while Hold operation
			d n - b o t t o m	Lower limit of bottom value while Hold operation
			U P - P e a k - P e a k	Upper limit of peak to peak value while Hold operation
			d n - P e a k - P e a k	Lower limit of peak to peak value while Hold operation
			U P - i n t e g r a t e d	Upper limit of integrated value
			d n - i n t e g r a t e d	Lower limit of integrated value
U P - c o u n t	Upper limit of the number of times of integration			
d n - c o u n t	Lower limit of the number of times of integration			

15	Condition of comparator 1-4	C o n d 0 0 0 0	xxx1	Compare only when measured value is stable.
			xx1x	Don't compare when measured value is close to zero.
			x1xx	Keep a comparison result and release it when measured value is close to zero.
			1xxx	Keep a comparison result and release it when a key is pushed.
			(0000 at the time of shipment)	
16	Reference value of window comparator	G o 0	-99999 to +99999	Set numerical value (0 at the time of shipment)
17	Upper limit of window comparator	H i 0	0 to 99999	Set numerical value (0 at the time of shipment)
18	Lower limit of window comparator	L o 0		
19	Judgement of window comparator	S E L 0 F F	0 F F	No judgement. No output. (at the time of shipment)
			n E t	Net value
			G r o S S	Gross value
			P E A k	Peak value while Hold operation
			b o t t o m	Bottom value while Hold operation
			P E A k - P E A k	Peak to peak value while Hold operation
			I n t e g r a t e d	Integrated value
20	Condition of window comparator	C o n d 0 0 0 0	xxx1	Compare only when measured value is stable.
			xx1x	Don't compare when measured value is close to zero.
			x1xx	Keep a comparison result and release it when measured value is close to zero.
			1xxx	Keep a comparison result and release it when a key is pushed.
			(0000 at the time of shipment)	
21	Polarity of window comparator	p o l H i G o L o	H i G o L o	Judge when plus / minus data (at the time of shipment)
			P - H i G o L o	Judge only when plus data

#### 8-4) External output

O U T					
No.	Content	Guide display	Setting value or candidate		Operation
1	Output 1	o S E L. 1 S P 1	S P 1		Comparator judgement result
2	Output 2	o S E L. 2 S P 2	S P 2	S t a b l e	Measured value is stable
3	Output 3	o S E L. 3 S P 3	S P 3	n e a r - 0	Measured value is close to zero.
4	Output 4	o S E L. 4 S P 4	S P 4/ L o	G r o S S	During Gross value

5	Output 5	o SEL.5 StAbLE	G o	t Ar E	During Tare subtraction
6	Output 6	o SEL.6 nEAr-0	H ,	H oL d	During Hold operation
				t o t Ar L	During integration
SEL.1=SP1, SEL.2=SP2, SEL.3=SP3, SEL.4=SP4, SEL.5=StAbLE, SEL.6=nEAr-0 at the time of shipment					

#### 8-5) External input

I n				
No.	Content	Guide display	Setting value or candidate	Operation
1	Input 1	i SEL.1 R 2	n o n	No input allowed
2	Input 2	i SEL.2 R 2 - r	R 2	Tare subtraction (equivalent <b>AZ</b> key)
3	Input 3	i SEL.3 Z Er o	R 2 - r	Clear Tare subtraction (equivalent <b>AZR</b> key)
4	Input 4	i SEL.4 H oL d	n E t - G r o S S	Display Gross value while ON. Display Net value when OFF.
5	Input 5	i SEL.5 A d d	H oL d	Hold operation while ON. Stop Hold operation when OFF.
6	Input 6	i SEL.6 t t L - C L E A r	d , S P	Indicate an item in order at Sub Display (equivalent <b>DISP SEL</b> key)
			Z Er o	Zero correction
			Z Er o . C L E A r	Clear zero correction
			A d d	Addition operation
			C A n c E L	Cancel addition operation
			t t L - C L E A r	Clear integrated value
			C n P - r E S E t	Release a comparator kept result.
P r i n t	Output data to RS-232C or RS-485 for once			
SEL.1=AZ, SEL.2=AZ-r, SEL.3=ZEro, SEL.4=HoLd, SEL.5=Add, SEL.6=ttL-CLEAr at the time of shipment				

#### 8-6) Analog output

d R o U t					
No.	Content	Guide display	Setting value or candidate	Operation	
1	Select data of current output	i - S E L n E t	n E t	Net value (at the time of shipment)	
			G r o S S	Gross value	
			H oL d	Sampling Hold value	
			P E A k	Peak Hold value	
			b o t t o m	Bottom Hold value	
2	Scale to 4mA output	d S P. 4 0	-99999 to +99999	Set numeric value (0 at the time of shipment)	
			-99999 to +99999	Set numeric value (10000 at the time of shipment)	
				R d d. 4 0	Select numeric value (0 at the time of shipment)
				-999 to +999	Select numeric value (0 at the time of shipment)
					R d d. 2 0 0
3	Scale to 20mA output	d S P. 2 0 1 0 0 0 0	-99999 to +99999	Set numeric value (10000 at the time of shipment)	
			R d d. 4 0	Select numeric value (0 at the time of shipment)	
4	Fine adjustment of 4mA output	R d d. 4 0	-999 to +999	Select numeric value (0 at the time of shipment)	
			R d d. 2 0 0	Select numeric value (0 at the time of shipment)	
5	Fine adjustment of 20mA output	R d d. 2 0 0	-999 to +999	Select numeric value (0 at the time of shipment)	
			R d d. 2 0 0	Select numeric value (0 at the time of shipment)	

6	Select data of voltage output	V - S E L n E t	n E t	Net value (at the time of shipment)
			G r o S S	Gross value
			H o L d	Sampling Hold value
			P E A K	Peak Hold value
			b o t t o m	Bottom Hold value
P E A K - P E A K	Peak to peak Hold value			
7	Scale to 0V output	d S P. 0 0	-99999 to +99999	Set numeric value (0 at the time of shipment)
8	Scale to 10V output	d S P. 10 10000	-99999 to +99999	Set numeric value (10000 at the time of shipment)
9	Fine adjustment of 0V output	A d J. 0 0	-999 to +999	Select numeric value
10	Fine adjustment of +10V output	A d J. 10 0		
11	Fine adjustment of -10V output	A d J. - 10 0		
				(0 at the time of shipment)

#### 8-7) Serial output

S E R I A L				
No.	Content	Guide display	Setting value or candidate	Operation
1	Select transmitting data of Current Loop	C L. S E L n E t	n E t	Transmit Net value (at the time of shipment)
			G r o S S	Transmit Gross value
			t o t A L	Transmit integrated value
			t e L - c o u n t	Transmit the number of times of integration
			d i S P	Transmit displayed value
2	Data format of Current Loop	C L. F o r m a t	-	No value nor candidate
3	RS-232C / RS-485 Mode	r S. m o d S e r E A n	S e r E A n	Transmit only (at the time of shipment)
			c o m m a n d	Receive command and Transmit data
			A u t o	Transmit only one time automatically when measured value is stable outside of close to zero. Prohibit to transmit again until measured value is close to zero.
			P - A u t o	Transmit only one time automatically when measured value is stable and positive outside of close to zero. Prohibit to transmit again until measured value is close to zero.
4	Select transmitting data of RS-232C / RS-485	r S. S E L n E t	n E t	Transmit Net value (at the time of shipment)
			G r o S S	Transmit Gross value
			t o t A L	Transmit integrated value
			t e L - c o u n t	Transmit the number of times of integration
			d i S P	Transmit displayed value

5	Data format of RS-232C/RS-485	r S. F n t F o r n A t t	-	No value nor candidate
6	Data speed of RS-232C/RS-485	r S. b P S 2 4 0 0	2 4 0 0	2400bps (at the time of shipment)
			4 8 0 0	4800bps
			9 6 0 0	9600bps
			1 9 2 0 0	19200bps
			3 8 4 0 0	38400bps
7	Data protocol of RS-232C/RS-485	r S. P r o 7 E u E n 2	7 n o n 1	7/8: Data bit length Non/Even/Odd: Data parity 1/2: Data stop bit length  ( 7Even2 at the time of shipment)
			7 E u E n 1	
			7 o d d 1	
			8 n o n 1	
			8 E u E n 1	
			8 o d d 1	
			7 n o n 2	
			7 E u E n 2	
			7 o d d 2	
			8 n o n 2	
8 E u E n 2				
8 o d d 2				
8	Transmit timing of RS-232C/RS-485	r S. c Y c d , 5 P	d , 5 P	Synchronized with renew period of displaying (at the time of shipment)
			S A n P	Synchronized with sampling incoming signal
9	Identification number of RS-485	r S. i d	n o n	No identification number (at the time of shipment)
			L 0 1 to L 9 9	L : Identifier 01 to 99 : Identification number

#### 8-8) BCD data output

b c d				
No.	Content	Guide display	Setting value or candidate	Operation
1	Select data of BCD output	b c d . S E L n E t	n E t	Net value (at the time of shipment)
			G r o S S	Gross value
			t o t A L	Integrated value (lower six digit)
2	Logic of BCD output	b c d . L O C 0 0 0 0 0	xxxx1	Logic of data signal
			xxx1x	Logic of OVER FLOW signal
			xx1xx	Logic of POLARITY signal
			x1xxx	Logic of STROBE signal
			1xxxx	Logic of STABLE signal
			0 = Negative logic, 1 = Positive logic (00000 at the time of shipment)	




#### 8-9) Weighing condition setting

F. c R L				
No.	Content	Guide display	Setting value or candidate	Operation
1	Digital Filter	d. F i L t e r 5	0	Filter disabled (Quick response)
			1	Filter weak
			2	Filter middle
			3	Filter middle (eliminate 60Hz)
			4	Filter middle (eliminate 50Hz)
			5	Filter strong (eliminate 50/60Hz) (Slow response but stable) (at the time of shipment)

2	Condition of moving average	R u . c o n d O F F	O F F 0.5 d, 1.0 d, 1.5 d, 2.0 d, 3.0 d, 4.0 d, 5.0 d, 6.0 d, 8.0 d, 10.0 d	Normal moving average (at the time of shipment) Clear moving average when measured value is out of the range specified here. d = minimum scale
3	Number of times of moving average	R u . t , n E 2 0 0 t	1 t, 10 t, 20 t, 50 t, 100 t, 200 t, 400 t, 600 t, 800 t, 1000 t, 1200 t, 1400 t, 1600 t, 1800 t, 2000 t	1t = No moving average  (200t at the time of shipment)
4	Condition of stable	S t . c o n d 1.0 d	O F F 0.5 d, 1.0 d, 1.5 d, 2.0 d, 3.0 d, 4.0 d, 5.0 d, 6.0 d, 8.0 d, 10.0 d	Always stable Range of measured value to judge to be stable d = minimum scale (1.0d at the time of shipment)
5	Time length to judge stable	S t . t , n E 1.0 s	0.0 s 0.1 s, 0.2 s, 0.3 s, 0.4 s, 0.5 s, 1.0 s, 1.5 s, 2.0 s, 2.5 s, 3.0 s	Judge immediately Time length to judge stable after fulfill condition of stable s = second (1.0S at the time of shipment)
6	Condition of zero tracking	Z t . c o n d O F F	O F F 0.5 d, 1.0 d, 1.5 d, 2.0 d, 3.0 d, 4.0 d, 5.0 d, 6.0 d, 8.0 d, 10.0 d	Zero tracking in ineffective (at the time of shipment) Range of zero tracking to be effective d = minimum scale
7	Working time of zero tracking	Z t . t , n E 1.0 s	0.0 s 0.1 s, 0.2 s, 0.3 s, 0.4 s, 0.5 s, 1.0 s, 1.5 s, 2.0 s, 2.5 s, 3.0 s	Zero track immediately Time length to work zero tracking after fulfill condition of zero tracking s = second (1.0S at the time of shipment)
8	Range of zero correction	Z r . L n i t 10	0 to 100 (%)	Range of zero correction Specify percentage of rated capacity set at [C R L / C R P] (10% at the time of shipment)
9	Renew period of displaying	d S P . c y c 2 0 t P s	1 t P s, 2 t P s, 5 t P s, 10 t P s,	Number of times to renew displaying per second.

			20tPS, 50tPS	(20tPS at the time of shipment)
--	--	--	-----------------	---------------------------------

8-10) Calibration

CAL				
No.	Content	Guide display	Setting value or candidate	Operation
1	Decimal point position	d.P o i n t 0	0	No decimal point (at the time of shipment)
			0.0	One digit after decimal point
			0.00	Two digit after decimal point
			0.000	Three digit after decimal point
			0.0000	Four digit after decimal point
			0.00000	Five digit after decimal point
2	Minimal scale	S c L d i u 1	1, 2, 5, 10, 20, 50, 100	Select numerical value  (1 at the time of shipment)
3	Rated capacity of Load Cell	CAP 99999	1 to 99999	Set numerical value as rated capacity of Load Cell (99999 at the time of shipment)
4	Zero calibration by actual load	CAL 0 0	0 only	Use   key to start to blink '0' Use  key to memorize
5	Span calibration by actual load	CAL 1 10000	-99999 to +99999	Set numerical value (10000 at the time of shipment)
6	Non linearity calibration by actual load	CAL 2 0	-99999 to +99999	Set numerical value  (0 at the time of shipment)
7		CAL 3 0		
8		CAL 4 0		
9		CAL 5 0		
10		Zero calibration by equivalent input		
11	Span display value by equivalent input	E.S.P A n 1 10000	-99999 to +99999	Set numerical value (10000 at the time of shipment)
12	Span calibration by equivalent input	E.S.A d d 1 1.00000	-9.99999 to +9.99999	Set numerical value (1.00000 at the time of shipment)
13	Non linearity calibration.  Span display value by equivalent input	E.S.P A n 2 0	-99999 to +99999	Set numerical value  (0 at the time of shipment)
14		E.S.P A n 3 0		
15		E.S.P A n 4 0		
16		E.S.P A n 5 0		

When non linearity (No.13~16) is modified other than 0, guide display 'E.S.A d d x' will appear to set calibration value (x is corresponding span number).

Equivalent input calibration is effective when EXC=5V. When EXC=2.5V calibration should be done by actual load.

It can be a cause of measurement error to change excitation voltage (EXC) after calibration has been done.











## § 9. Test Mode





















The response of Open Corrector output and indication of display is different during Test Mode. Please take measures to connected external equipment to keep it from abnormality. Test Mode confirms conditions of this unit by manual operation.

Test Mode helps to check input and output of this unit. When a system has malfunction, it is useful to confirm whether this unit or connected external equipment has failure in Test Mode.

### 9-1) Basic operation

- 1) To enter Test Mode, Push  key while turning power ON, or press  key 3 times immediately after powered ON.  
Pressing  or  key and  key 3 times at [ F u n c / E E S E ] in Function Mode can also enter Test Mode.
- 2) To leave Test Mode, turn power OFF or pressing  key 3 times at displaying program version in Test Mode.
- 3) Proceed to the next item by  key and return to the previous item by  key.

### 9-2) Test item

No.	Guide display	Item	Description
1	5 0 3 7 P. XXX	Program version	press  key 3 times to return to Measuring Mode
2	8.8.8.8.8.8. 8.8.8.8.8.8.8.8.	LED check	Check all LED on front panel ① Turn ON all LED ② Turn OFF all LED ③ Turn ON each segment of digit LED ④ Turn ON every digit LED in order
3	E E 4 5.0            0	Key check	Left side : Excitation voltage Right side : Allocated key number 0 = No key pressed, 1=  , 2=  , 3=  , 4=  , 5=  , 6=  , 7=  , 8=  , 9= 
4	0 u t o o o o o o	External output check	Output 1 is ON/OFF by  key Output 2 is ON/OFF by  key Output 3 is ON/OFF by  key Output 4 is ON/OFF by  key Output 5 is ON/OFF by  key Output 6 is ON/OFF by  key
5	l n o o o o o o	External input check	oooooo : No external input is ON 1ooooo : Input 1 is ON o2oooo : Input 2 is ON oo3ooo : Input 3 is ON ooo4oo : Input 4 is ON oooo5o : Input 5 is ON ooooo6 : Input 6 is ON
6	d R. o u t 1 2.0 n A        0 u	Analog output check	Decrease analog output by  key. Increase analog output by  key. 11 steps as follows 4.0mA -10V            13.6mA 2V 5.6mA -8V            15.2mA 4V 7.2mA -6V            16.8mA 6V 8.8mA -4V            18.4mA 8V 10.4mA -2V            20.0mA 10V 12mA 0V Indicate even if OP-1 / 2 is not installed.
7	S E r i A L (no option) c. L (OP-3) r 5 - 2 3 2 c	Serial communication check	Transmit 'WT,+000000' by pushing   key. Transmit 'WT,+000000' as answer back when received 'REQ' command of RS-232C / RS-485.

	(OP-7) r 5 - 4 8 5		Protocol and speed follow settings at [SEriAL / rS.bPS] and [SEriAL / rS.Pro] in Function Mode. At RS-485, no identification is made. One to one communication
8	b c d (no option) n c (OP-6) F F F F F F F	BCD check	Only effective when OP-6 is installed ① All output is ON (Negative logic : Low level) ② All output is OFF (Negative logic : High level) ③ Output 1 bit for all digit. (4 bit) ④ Output 'F' for each digit. (1111B)
9	5 t r R i n X.XXXX	Check input voltage from Load Cell	Display input voltage from Load Cell (mV/V) Using <b>AZ</b> or <b>AZR</b> key can let the display value be zero or restore a previous value.

---

## § 1 0 . Troubleshooting

---

If this unit does not work properly, please take the following measures. If the trouble still cannot be solved, then please contact our company.

At query, please inform us the model name, product serial number, and conditions of this unit as detailed as possible.

### 10-1) Basic check point

- 1) Please check if using a correct power supply. this unit is supplied with voltage AC100~240V as standard or DC24V as option.
- 2) Please check that wires are connected to the terminal base properly.

### 10-2) Precautions at the time of calibration

- 1) Error occurs at the time of zero point calibration.
  - In case of exceeding the setting range of zero point.  
To perform zero point calibration, Load Cell output with no load should be in the range of  $-2.8\sim+2.8\text{mV/V}$   
If using Load Cell which has rated output more than  $3.3\text{mV/V}$  and its no load output exceeds  $\pm 2.8\text{mV/V}$ , please contact our company.
- 2) Error occurs at the time of span calibration, or display value is not correct as set in span calibration.
  - In case of output voltage of Load Cell being large.  
This unit cannot measure in a system that the sum of initial tare value and measured value exceed  $3.3\text{mV/V}$ .  
If using Load Cell which has rated output more than  $3.3\text{mV/V}$ , please contact our company.
  - In case of span calibration voltage is slight.  
If span of Load Cell output with a load is lower than the setting value of span, calibration is incorrect.  
Make resolution rougher to set minimum scale higher, or use an appropriate Load Cell.
- 3) Fluctuation of measured value
  - Inappropriate span setting value against resolution.  
Since the input sensitivity of this unit is  $0.5\mu\text{V}/\text{digit}$ , the maximum display resolution is  $1/10,000$  when input  $1.0\text{mV/V}$ . Exceeding this resolution makes fluctuation obviously.  
Set minimum scale higher to make fluctuation less to the degree not perceivable.

### 10-3) Countermeasures for unusual display

- Measured value is blinking (over load indication) when not overloaded.  
A part of sensor cable might be broken or a sensor itself might be defective.  
Please confirm the input voltage (mV/V) from a sensor in Test Mode.

### 10-4) Judgement whether this unit has malfunction

- 1) Please confirm whether a sensor excitation voltage is correct.  
Disconnect a sensor from this unit and check the voltage by a tester between #1(+EXC) and #4(-EXC) of terminal block. Please check whether it is stable at  $5\text{V}\pm 0.5\text{V}$  (EXC=5V).  
If it is unstable, power circuit for a sensor in this unit is failure.
- 2) Short-circuit ( Jumper between No.5 (+SIG)~No.6 (-SIG) ) at terminal block.  
Display input voltage (mV/V) in Test Mode. Then check if the input voltage is stable nearest to zero. If unstable, this unit is failure. If stable, please check a sensor side.
- 3) Check external input / output  
Check external input / output in Test Mode.

10-5) Checking a sensor (Load Cell)

Good or bad rough judgement can be done by measuring input/output resistance and insulation resistance because the Load Cell is structured by a bridge circuit. ( Please make sure to power OFF this unit first and disconnect Load Cell before checking resistance)

1) Fault judging method by resistance of Load Cell

Check bridge resistance of Load Cell by a tester and confirm whether input/output resistance are correct

2) Fault judging method by insulation resistance of Load Cell

Measure the insulation resistance between shield line and other with voltage less than 50V. If the insulation resistance shows more than 1000M $\Omega$ , insulation of Load Cell is no problem.

---

## § 1 1. Specifications

---

### 11-1) A/D convert part

- 1) Input sensitivity: 0.5 $\mu$ V/digit  
Resolution: Max. 1/10,000 at 1.0mV/V input (EXC=5V)
- 2) Non-linearity:  $\pm 0.03\%$ FS $\pm 1$  count
- 3) Temperature characteristics: Zero point  $\pm 0.005\%$ FS/ $^{\circ}$ C (at 1.0mV/V input)  
Sensitivity  $\pm 0.005\%$ Reading/ $^{\circ}$ C
- 4) Frequency characteristics: select 12 cut-off frequency(-3dB) from 2Hz to 4kHz  
-12dB/oct. low pass filter
- 5) Transducer power supply: DC5V $\pm 5\%$  60mA or 2.5V $\pm 5\%$  with remote sensing circuit  
Four 350 $\Omega$  type sensors can be connected
- 6) ADC sampling cycle: approx. 0.5ms (2000 times/sec)

### 11-2) Display part

#### 1) Main Display (measured value)

- ①Element: LED 7-segment, 5-digit, Orange, character height 10mm
- ②Maximum reading:  $\pm 9999$  (Zero suppress reading)
- ③Decimal point: Select 1~5 digit after decimal point  
(Nil, 0.0, 0.00, 0.000, 0.0000, 0.00000)
- ④Over indication: All digit Blink when measured value exceeds capacity  
and when voltage from sensor exceeds  $\pm 3.3$ mV/V
- ⑤Unit: kg  
Other unit is pasted by unit seal as follows.  
kg, g, t, N, kN, N $\cdot$ m, kN $\cdot$ m, kPa, MPa, mm, %
- ⑥Renew cycle: select from 1, 2, 5, 10, 20, 50 times/second

#### 2) Sub Display

- ①Element: LED 7-segment, 9-digit, Orange, character height 8mm
- ②Content: Select a content using DISP SEL key  
Tare subtraction, Preset tare subtraction, Integration target gap, Integration target value, Integration number of times, Sampling Hold value, Peak Hold value, Bottom Hold value, Peak to peak Hold value, Conversion(Bar graph, Percentage, Unit conversion)

#### 3) Status Display

- ①Element: 11 round shape LEDs,  $\Phi 3$ mm, red  
3 square shape LEDs, red, green, yellow
- ②Status: Upper side:  
ST:Stable, CZ:Center zero, Gross:Gross value,  
AZ:Tare subtraction, PT:Preset tare subtraction,  
HOLD:Hold, \*:User selected function  
Down side:  
SET POINT 1 to 4 : Comparator 1 to 4 status  
LO/GO/HI: Window comparator status

### 11-3) Zero point and Sensitivity correction

- 1) Zero point correction: adjustable by input signal of  $-3\sim+3$ mV/V
- 2) Sensitivity correction: adjustable by span volume of  $-3.3\sim+3.3$ mV/V  
※ The sum of zero point and span amount should not exceed  $\pm 3.5$  mV/V.
- 3) Correction method: Actual load calibration or Equivalent input calibration (only when EXC=5V)
- 4) Accuracy of Equivalent input:  $\pm 0.2\%$ FS (span amount 1mV/V and cable length 1m)  
only when EXC=5V

#### 11-4) I/O part

##### 1) Operation switches

- ① Key switch: 9 keys
- ② Slide switch: 3 switches on rear side.

##### 2) External input

6 inputs (6bit, 1bit common)  
Contact input without voltage or Open Collector input  
( $I_c=10\text{mA}$ , voltage endurance more than 20V)  
0.2s one shot MAKE signal or MAKE signal

##### 3) External output

- ① Output signal: 6 outputs (6bit, 1bit common)  
Open Collector output (photo coupler insulation)
- ② Rated output: DC30V 50mA (resistance load), saturation voltage  $\leq 1.2\text{V}$

#### 11-5) Option

##### 1) OP-1: 4 to 20mA current output

- ① Output signal: DAC output linked with ADC sampling
- ② Output range: 3.2 to 20.8mA
- ③ Resolution: linked with display resolution (maximum 1/10,000)
- ④ Load resistance:  $510\Omega$  or less
- ⑤ Non linearity: 0.1%FS (for display level)
- ⑥ Temperature characteristic: 0.01%FS/°C for zero point and sensitivity

##### 2) OP-2: 0 to $\pm 10\text{V}$ voltage output

- ① Output signal: DAC output linked with ADC sampling
- ② Output range: 0 to  $\pm 10\text{V}$
- ③ Resolution: linked with display resolution (maximum 1/10,000)
- ④ Load resistance:  $5\text{k}\Omega$  or more
- ⑤ Non linearity: 0.1%FS (for display level)
- ⑥ Temperature characteristic: 0.01%FS/°C for zero point and sensitivity

##### 3) OP-3: RS-232C serial communication

- ① Interface standard: EIA RS-232C conformity
- ② Communication protocol: Start-Stop Synchronous (Asynchronous) type / Half Duplex bi-directional
- ③ Communication speed: 2400, 4800, 9600, 19200, 38400bps
- ④ Data length: 7, 8 bit
- ⑤ Data parity: Non, Even, Odd
- ⑥ Data stop bit: 1, 2bit
- ⑦ Data format: TOYO dedicated format, ASCII code

##### 4) OP-6: BCD data output

- ① Interface: Open Collector output (isolated by a photo coupler)
- ② Rated output: DC30V 30mA (resistance load), saturation voltage  $\leq 0.6\text{V}$
- ③ Renew period of data: Synchronized with renew period of displaying, maximum 20 times/second (50ms)
- ④ Output logic: Select positive or negative
- ⑤ Output format: 28 bit length, no parity

##### 5) OP-7: RS-485 serial communication

- ① Interface standard: EIA RS-485 conformity (4-lines)
- ② Communication protocol: Start-Stop Synchronous (Asynchronous) type / Half Duplex bi-directional,
- ③ Communication speed: 2400, 4800, 9600, 19200, 38400bps
- ④ Data length: 7, 8 bit
- ⑤ Data parity: Non, Even, Odd
- ⑥ Data stop bit: 1, 2bit
- ⑦ Data format: TOYO dedicated format, ASCII code
- ⑧ Maximum connectable unit: 10 units

11-6) General

- ① Countermeasure for power failure: Each data is written in a non-volatile memory
- ② Power supplied voltage: AC85~264V、50/60Hz、20VA as standard  
DC20~27V、0.5A as option
- ③ Operating Temperature and Humidity range: -10~40℃、20~85% R.H. (without condensation)
- ④ Mounting: Panel mounting type
- ⑤ Mass: approx. 1 kg

---

**§ 1 2. List of Models and Accessories**

---

12-1) Model

D L S - 5 0 3 7 - 1 - D C

Power supplied  
voltage  
Option

- blank : AC100 to 240V as standard
- DC : DC24V as option
- blank : No option
- 1 : Current output (4 to 20mA)
- 2 : Voltage output (0 to ±10V)
- 3 : RS-232C communication
- 6 : BCD data output
- 7 : RS-485 communication

Model name

Digital indicator DLS-5037

12-2) Accessories

- 1) Operation Manual 1 copy
- 2) Unit seal 1 pc.
- 3) Terminal cover 2 pcs.
- 4) Metal piece for SEN terminal 2 pcs. (Already assembled to the terminal)
- 5) FCN Connector for I/O (16pin) 1 pc.

### § 1 3. Terminal array

#### 13-1) Terminal array

##### 1) Terminal for Load Cell (7.62mm pitch crimped terminal)

No	Signal connection	
1	+EXC	Excitation voltage to Load Cell (+)
2	+SEN	Remote sensing input (+)
3	-SEN	Remote sensing input (-)
4	-EXC	Excitation voltage to Load Cell (-)
5	+SIG	Input signal from Load Cell (+)
6	-SIG	Input signal from Load Cell (-)
7	SHL	Shield line of Load Cell cable

Load Cell should be connected by a shielded cable of 6 cores. If shielded cable of 4 cores are used, use a metal short piece to connect #1 to #2 and #3 to #4 of terminal.

Also make it apart from a noisy line or AC line.

Please connect correctly after confirmed a signal name and cable color referring to Test Report attached to the Load Cell because cable wiring color is different from a manufacturer or a model.

##### 2) Terminal for analog output and power line (7.62mm pitch crimped terminal)

No.	Signal connection			
8	A-OUT+	Analog output (+) (option)		
9	A-OUT-	Analog output (-) (option)		
10	S-OUT	Current Loop output		
11		(No polarity)		
12	E	Earth		
13	AC (L)	Power supplied voltage	DC (+)	Power supplied voltage
14	AC (N)	(AC100 to 240V)	DC (-)	(DC24V)

Please connect #12(E) to the earth-line with ground resistance 100Ω or less.

Power supplied voltage is AC100 to 240V (standard) or DC24V (option). Please check the name plate of this unit and confirm whether the supplied voltage is correct.


In case of AC powered, please make twist of power wires.

##### 3) Terminal for external I/O (FCN connector)

I/O	No.	Signal connection	
		A side	B side
Input	1	External input 1	External input 2
	2	External input 3	External input 4
	3	External input 5	External input 6
	4	Common ground for external input	
Output	5	External output 1 (Comparator 1)	External output 2 (Comparator 2)
	6	External output 3 (Comparator 3)	External output 4 (Comparator 4 / Window comparator LO)
	7	External output 5 (Window comparator GO)	External output 6 (Window comparator HI)
	8	Common Emitter for external output	

Conformed connector : Fujitsu Component Limited FCN-361J016 (16pin female)


Do not bundle with AC power wire or drive motor wire to avoid malfunction



(Rear side of this unit)



## § 1 4. Dimensional Drawing



## § 1 5. Functional Block Diagram

